

## Installation Instructions Bolt-On Spoiler w/o Light

**Lifetime  
Warranty**

**Kit Includes:**

Spoiler  
Gaskets  
Locator Strips  
Mounting Screws  
(4) Access Hole Plugs

**Tools Required:**

Drill  
Drill Bits (1/8", 5/16", and 3/4")  
Panel Puller  
3/8" Ratchet or Nut Driver  
Measuring Tape  
Masking Tape

**Important: Always test fit part before prepping, painting or drilling holes.**

**Step 1.**

Start out by removing the trunk liner if one exists (See figure 1). Place the locator strips into the mounting holes on spoiler. A small piece of masking tape is helpful in holding the locator strips in position (See figure 2).



FIGURE 1



FIGURE 2

**Step 2.**

Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a perfect alignment (See figure 3).



FIGURE 3



FIGURE 4

**Step 3.**

Using masking tape, secure locator strips to the decklid of the vehicle (See figure 4). Simply remove the spoiler by lifting straight up, leaving the locator strips still secured to the decklid. (See figure 5)

**Step 4.**

Using a 1/8" drill bit, drill thru the locator strip holes and into the decklid. (See figure 6)



FIGURE 5



FIGURE 6

**Step 5.**

Remove locator strips and using a 5/16" drill bit or we prefer a unibit, drill thru the 1/8" hole in step 4. (See figure 7)

**Step 6.**

Pull back pedestal gaskets exposing mounting tape and place spoiler on decklid and using supplied screws secure to the vehicle using a ratchet or nutdriver. **Do not use drill to tighten screws, as you may drive the screw through the top of the spoiler.** (See Figure 8)



FIGURE 7



FIGURE 8

TIP:Gasket material is extremely sticky once exposed, so we found that spraying it with water or glass cleaner will allow you to reposition spoiler as needed.

**Step 7.**

Apply small amounts of silicone based caulk over mounting screws as this will help prevent leaking, rusting or loosening of screws. (See figure 9) Insert access hole plugs.



FIGURE 9



FINISHED PRODUCT!

**Step 8.**

Finish your install by vacuuming any debris or metal shavings, reinstall any panels, mats or items that may have been removed earlier.