



1. Test fit the product to make certain the product you have fits the vehicle you intend to install it on. Determine the exact location to place the trim **BEFORE** you prep the surface (on door handles with keyholes, line up the keyhole area first to ensure proper operation of the key).



2. Wash area of the application with soap and water, then thoroughly dry.



3a. Thoroughly clean the area with isopropyl alcohol to remove any grease, wax or oils left on the surface.

3b. If your product includes an adhesive promoter, apply it only to the surface which the trim will cover. (Do not apply directly to the tape on the product)



4. Start to remove the backing from the 2-sided tape. Pull back 1-2 inches and bend the backing back to create a pull tab that extends form behind the product. Do this for each piece of tape on the product. If the tape is too small to create a tab then remove the backing completely. (if you are having trouble removing the backing film from the two-sided tape, use your finger to "flick" the end of the tape)



5. Install the piece onto the vehicle, in the exact location you used for your test-fit. (on door handles with keyholes – line up the keyhole area first to ensure proper operation of the key)

6. Pull the tabs of tape that are sticking out from behind the piece, to remove the rest of the liner off the tape, while you are applying pressure to the item.



7. Apply pressure with the palm of your hand. Use firm pressure all the way around the piece to insure proper adhesion.

Repeat this process for the remaining trim pieces in the package.



1. Test fit the product to make certain the product you have fits the vehicle you intend to install it on. Determine the exact location to place the trim **BEFORE** you prep the surface (on door handles with keyholes, line up the keyhole area first to ensure proper operation of the key).



2. Wash area of the application with soap and water, then thoroughly dry.



3a. Thoroughly clean the area with isopropyl alcohol to remove any grease, wax or oils left on the surface.

3b. If your product includes an adhesive promoter, apply it only to the surface which the trim will cover. (Do not apply directly to the tape on the product)



4. Start to remove the backing from the 2-sided tape. Pull back 1-2 inches and bend the backing back to create a pull tab that extends form behind the product. Do this for each piece of tape on the product. If the tape is too small to create a tab then remove the backing completely. (if you are having trouble removing the backing film from the two-sided tape, use your finger to "flick" the end of the tape)



5. Install the piece onto the vehicle, in the exact location you used for your test-fit. (on door handles with keyholes – line up the keyhole area first to ensure proper operation of the key)

6. Pull the tabs of tape that are sticking out from behind the piece, to remove the rest of the liner off the tape, while you are applying pressure to the item.



7. Apply pressure with the palm of your hand. Use firm pressure all the way around the piece to insure proper adhesion.

Repeat this process for the remaining trim pieces in the package.

