

FENDER FLARE INSTALLATION INSTRUCTION FORD F-150 RAPTOR 09-UP

Parts

Qty (1) Fender Flare Left Front (LF)
Qty (1) Fender Flare Left Rear (LR)
Qty (1) Fender Flare Right Front (RF)
Qty (1) Fender Flare Right Rear (RR)


Qty (1) Rubber Seal (enough for four flares's outer edge)
Qty (2) Long Clip & Truss Type-A Screw
Qty (16) Plastic Fastener
Qty (36) Allen Bolt, Nut & Washer (Torx Bit required)
Qty (8) Self Tapping Screws (see option B)

Step 1. Pre-Installation



Prefit both driver side and passenger side fender flares to the vehicle before painting or installation. You may remove any moldings, strips or existing flares from the vehicle for fitting or installation. You can cut the fender flare to fit any body side molding.

Step 2. Painting (optional)




Professional paint or body shop recommended to paint flares. Follow all the paint manufacture specifications to paint the flares. Clean fender flare surfaces with clean water and a mild detergent before painting, do not use lacquer thinner or any solvent based products.

Step 3. Cleaning




Wash and wipe dry the areas of contact on the vehicle body. Clean the surface and inside edge of the fender flare where the rubber seal is to be attached.

Step 4. Apply Rubber Seal




Apply rubber seal to the flare. Start at one end of the flare along the edge that comes in contact with the body panel. Apply pressure on the tape to ensure adhesion, and trim excess rubber seal at the end. To avoid bulge you may cut a notch in the edge of rubber seal at the inward angle curve, cut a V out for the outward angle curve.

Step 5. Installation (Left Front Flare Shown)



Use torx bit to tighten allen bolt & put firmly on every pocket of the fender flares. Remove OEM flare & existing screws from the vehicle. Place the flare on the vehicle, mark the forward hole location into the vehicle and apply a long clip over the mark in between the vehicle and the flare. Secure the flare with a Truss Type screw into the long clip. Apply 2 Plastic Fasteners into the mounting slot in the flare and secure it to the vehicle as shown. Re-Install the existing factory screws into the original location that were previously removed. Do not tighten the screws fully until the flare is aligned and extrusive against the body.

Step 6. Installation (Left Rear Flare Shown)



Use torx bit to tighten allen bolt & put firmly on every pocket of the fender flares. Remove OEM flare & existing screws from the vehicle. Place the flare on the vehicle. Apply 5 Plastic Fasteners into the mounting slots in the flare and secure it to the vehicle as shown. Re-Install the existing factory screw into the original location that were previously removed. Do not tighten the screws fully until the flare is aligned and extrusive against the body.

Option B: If condition of fender prevents use of the Push-In Clips you can use the included self tapping screws to secure the flare to the fender.

855-787-8334

www.trueedgeproducts.com